# VIDEOINSIGHT

End User Guide Viewing Live and Recorded Video Version 4.15

VIDEO INSIGHT, INC. 3 RIVERWAY, STE 700 HOUSTON, TX 77056

		INSIGHT, INC.	
		RWAY, STE 700	
	HOUST	ΓΟΝ, TX 77056	1
1	SOF	TWARE OVERVIEW	5
1	<b>50</b> F		
	1.1	BASIC SYSTEM	5
	1.2	ADDITIONAL PRODUCTS	5
2	MO	ΝΙΤΩΡ ΩΤΑΤΙΩΝ ΩΩΡΕΕΝ Ι Αναμτ	(
2	MU	NITOR STATION SCREEN LAYOUT	0
	2.1	LOGIN	6
	2.2	VIEWING PANEL	8
	2.2.1	Layout Buttons	8
	2.2.2	Camera Image	8
	2.2.3	Title Bar	9
	2.2.4	Right Click on Image	9
	2.2.5	Left Click to Zoom and Picture within a Picture	.10
	2.3	LEFT PANEL NAVIGATION TREE STRUCTURE	.11
	2.3.1		
	2.3.2		
	2.3.3		
	2.3.4		
	2.3.5		
	2.3.6	Facility Map View	. 15
	2.3.7		
	2.3.8	0	
	2.4	PTZ AND AUDIO CONTROLS	
	2.4.1		
	2.4.2		
	2.5	RECORDED VIDEO	
	2.5.1		
	2.5.2		
	2.5.3	0 1	
	2.5.4	1	
	2.5.5	0 2	
	2.5.6		
	2.5.7		
	2.5.8	Object Zoom and Print MEDIA PLAYER	
	2.6		
	2.6.1 2.6.2		
	2.6.2		
	2.6.4		
	2.6.5	1	
	2.6.6	0	
	2.6.7		
	2.6.8		
	2.6.9		
	2.6.1		
	2.6.1		
	2.6.1	•	
	2.6.1		
2			
3	PUL	L DOWN MENUS	.33
	3.1	FILE	. 33
	3.1.1	Media Fixer	. 33
	3.1.2		
	3.2	VIEW	. 33
	3.2.1	-5	. 34
	3.2.2		
	3.2.3		
	3.2.4	Layout Order	. 34

3.2	2.5 MiniToolbars	
3.2	2.6 Status	
3.2		
3.3	TOOLS	
3.3	3.1 System Log	
3.3		
3.3	3.3 Live Window	
3.3	3.4 PTZ Operations	
3.3	3.5 Synchronized Playback	
3.3	3.6 Media Player	
3.3	3.7 Options	
3.4	ADMINISTRATION	
3.5	Help	
3.5	5.1 License Agreement	
3.5	5.2 Online IP address	
3.5	5.3 Online Support	
3.5	5.4 Remote Support	
3.5	5.5 About Video Insight	
4 WI	EB CLIENT	40
4.1	SUPPORT FOR MOBILE DEVICES	
4.2	SCREEN LAYOUT	
4.3	LEFT NAVIGATION TREE STRUCTURE	
4.3	1	
4.3		
4.3		
4.3		
4.4	VIEWING PANEL	
4.4		
4.4		
4.5	WEB CLIENT TOOL BAR	
4.5		
4.5	· · · · · · · · · · · · · · · · · · ·	
4.5		
4.5		
4.5		
4.6	HELP	
4.6		
4.6	0	
4.6	1	
4.6		
4.6	6.5 About Video Insight	

# 1 Software Overview

## 1.1 Basic System

Our product is a robust software platform that has 3 main components that are used to capture and view live or recorded video from anywhere: the Service Monitor; the Monitor Station; and the Web Client.



<u>IP Server</u> – The IP Server is the basic engine of the product suite. It processes and stores images received from all connected IP cameras as well as streams video to the client for viewing. The IP Server is installed on a standard Windows based PC and runs as a Windows service. The Server can be linked to other servers to support hundreds of cameras. With software solution you can have a single server, multiple servers at one location or multiple servers at multiple locations. Recordings can be stored on local or direct attached storage, NAS, SAN, or Network File Servers. As part of our powerful infrastructure, the system stores all settings and log entries inside Microsoft SQL database tables. This gives the software a very solid platform to deliver advanced features.

<u>Monitor Station</u> – The Monitor Station is the primary user interface in the product suite. From an end user point of view, it provides centralized viewing of live and recorded images from any server. System and Security Administrators use the Monitor Station to setup and configure all servers and cameras from a central location.

<u>Web Client</u> – Allows you to view live or recorded video from anywhere with using Microsoft Internet Explorer. You can view a single camera or select up to 16 different cameras from multiple servers to view simultaneously. You can control PTZ cameras and playback recorded video. The system supports multiple users and is tightly integrated into the Windows operating system for complete security.

## 1.2 Additional Products

In addition, software suite also provides the following accessory products to assist you in managing your servers and cameras:

<u>Health Monitor</u> – The Health Monitor monitors each of your servers on a regular basis to ensure server uptime and reporting of any issues affecting the servers. The Health Monitor can be configured to send email alerts to the appropriate individual if the server has not responded in the predetermined time frame or if certain thresholds have been exceeded. The Health Monitor status windows can also be viewed in the Monitor Station

<u>LTS – Long Term Storage</u>- The LTS is a standalone application that helps you manage your recorded video. The easy to use application connects to the video data directory allowing you to Move, Recompress or Trim the original AVI files. The LTS can also recompresses the original AVI file using Microsoft's WMV format and is able to double the available storage space. You can specify which cameras to copy, how many days to keep before the copying and what time of the day to execute the copy. The new copied files can be viewed with any Windows Media Player.

# 2 Monitor Station Screen Layout

The Monitor Station has two primary functions: it records the video and provides tools to view live or recorded video. The system is designed to be easy to use while having very powerful features.

## 2.1 Login

When the Monitor Station is initiated, a system login screen appears:		
🖲 Monitor St	ation System Login 🛛 🔀	
Username	vicorp\mflick	
Password	*********	
	OK Cancel Options >>	
L	OK Cancel Options >>	

Check with your system administrator for your login information. For setting up users and groups, please see the Setup and Configuration Guide.

More options can be viewed by clicking on the Options button.			
Monitor St	tation System Login	×	
Username	vicorp\mflick		
Password	********		
	tation System Login Options	٦	
🔘 Sys	stem Administrator Mode		
🔘 Nel	twork User Mode		
Loc	cation of Data File		
	Browse		
📀 Wir	ndows Login		
Dor	main vicorp		
ſ	OK Cancel Options <<		
		_	

See your system administrator for most information on Options.

When you start the Monitor Station, the following screen appears:



There are three main sections of the screen:



Left Navigation tree structure (outlined in blue) which can be used to navigate from camera to camera and to view recorded files. •

· · · · · · · · · · · · · · · · · · ·
Enterprise view 💮 👘 🏢
📮 🔤 All Servers
🕀 🐏 Southwest Campus
🕀 🐏 Central High School
Southeast Campus
🛺 West Entrance
🔯 East Stairwell
🔯 Elementary School Wing
🛺 Cafeteria Cash Register
📬 West Entrance
📬 Main Entrance
🙋 Pick Up area
🛺 Front Circle Drive
🛺 School Bus Stop
📴 South Entrance
🛺 Back Circle Drive
🛺 North Entrance
🛺 Cafeteria
💼 Main Entrance
👰 Main lobby
🙍 Axis PTZ
连 📲 Layouts
🚊 🗄 📲 Facility Maps
🖶 📲 All Layouts
🖶 📲 All Facility Maps
All Action Items

Tool Bar (outlined in green) which provides convenient access to commonly used tools

File View Tools Administration Help

#### 2.2 Viewing Panel

The viewing panel can be configured to show from one to 32 cameras in various configurations.

#### 2.2.1 Layout Buttons

The layout buttons at the top of the viewing panel allow you to control the number of cameras displayed. Click on the 4 camera grid and it displays the first four cameras.

|--|--|--|

Click on the desired layout icon, and the viewing panel changes to reflect the new viewing configuration. You can also create any number of custom views and select the layout to display on startup. To create custom layouts, please see the Setup and Configuration manual.

#### 2.2.2 Camera Image

Each pane in the layout shows a consistent view of the image and supports easy to use icons and "Right Click" functionality.





At the top of the image is the name of the camera.

#### 2.2.3 Title Bar

On the top of each picture, there is a Title Bar with commonly used functions.

Turns orange if motion has occurred in the picture. Click to reset.



Freezes the Frame



Pops up a live window that can be repositioned on your screen

Replays the last 30 seconds of motion.

#### 2.2.4 Right Click on Image

By positioning the mouse on the image and right clicking, the following menu appears:

Ś	Full screen
	Live window
	Live audio
	Recent history
	Recorded media files
	Print image
	Save image
	Send
	Properties

#### **Full Screen**

The Full Screen option enlarges the image to cover the entire viewing panel.

#### Live Window

The Live Window option creates another Window containing the image. The user can then move that Window to anywhere on the screen or another screen if multiple monitors are setup.

#### Live Audio

The Live Audio option activates audio from that camera.

#### **Recent History**

The Recent History option automatically displays the last 30 seconds of recordings. If the camera is set to Motion Only Recording, there must be motion in the last 30 seconds in order for the 30 seconds of recording to display.

#### **Recorded Media Files**

This option brings up the Video Player. See the documentation on the Video Player below.

#### **Print Image**

Sends the image in the frame to the printer.

#### Save Image

The Save Image option brings up the Save As dialogue box and allows the user to save the current image to a local or networked storage device.

#### Send

The Send function allows the user to send a copy of that live viewing pane to anyone that is logged in to another Monitor Station. When the option is selected the following screen appears:

💿 Send to user 🛛 🔀
Select the users you want to view this camera.
All users
Administrator
pmilam
N mflick
🖄 Mike
🔲 james
idoe
Test User
OK Cancel

You can then select the users that you want to receive the live view of this camera. Please note that if the user does not have viewing rights to this camera, they will not receive the live view from the camera. In addition, only those users that are currently logged into the system will receive the live view from the camera.

#### Properties

The Properties option brings up the Property and Settings for that Camera. See the Setup and Configuration Manual for details on these settings.

#### 2.2.5 Left Click to Zoom and Picture within a Picture

To zoom in on a picture, position the mouse on the upper left hand corner of the area that you want to zoom in on, then press the left mouse button and drag the mouse over the area to be zoomed. The system will then zoom in on the area. To zoom out, position the mouse in the lower right hand corner, then press the left mouse button and drag the mouse back over the area. The system will then zoom out to the original view. You can then use the PTZ controls in the left pane to control the zoom function as a digital PTZ. You can click on the middle of the camera image to return to the normal view. When you use the zoom function, a picture within a picture displays in the lower left corner. The picture without the zoom displays in the picture within a picture within



Zoomed view with picture within picture.



You can also drag the orange box around the picture to create a digital PTZ control.

# 2.3 Left Panel Navigation Tree Structure

The Left Navigation Tree Structure provides the main means of navigating between locations and cameras. You can navigate to particular locations (servers) and cameras, or you can navigate to custom layouts and facility maps. The key elements found in the navigation tree are Servers/Cameras, Layouts, Facility Maps and Action Items. The following sections discuss each element in detail.

There are three different methods for navigating between locations and cameras: Enterprise, Facility Maps and Layouts.

These views can be selected by using the icons at the top of the Left Navigation Tree Structure



#### 2.3.1 Enterprise View

The Enterprise view has a structure of



#### 2.3.2 Elements in Left Navigation Tree Structure

#### Servers and Cameras

The list of Servers show in the left navigation tree is the list of all of the servers that this particular user has access to. A server is an instance of the software with various cameras attached. All Servers can be expanded to include a view of all servers



By selecting a particular server, all cameras from that server will be displayed in the viewing pane.

Each Server can then be expanded to show the cameras assigned to that server as well as any layouts or facility maps associated with that server.



When a particular camera is selected, that camera's live view will be displayed in the viewing pane.

Note that when a server or camera is operational, the icon to the left of the name will be green. If the server or camera is not operational, the icon will be orange.



You can set up customized layouts that can display cameras from one or multiple servers.



In the example above, the administrator has set up two custom layouts: one consisting of the Key Locations within the Southeast Campus and one of the Pickup areas of the Southeast Campus In the example above, when the layout "Front Entrances" is selected, the following view appears showing cameras at each entrance of each of 4 different campuses



Layouts are stored on particular servers. However, given the right security access, anyone on any server can view any custom layout. For more details on setting up custom layouts, consult the Setup and Configuration Guide.

#### **Dynamic Layouts**

You can also create dynamic layouts by selecting and dragging cameras onto the viewing panes. Select cameras from the left navigation tree and drag them into the desired viewing panes. Cameras can be selected from any server.

#### 2.3.3 Multi-Layered Facility Map

To help locate cameras across your organization, you can import images of your facilities into the system. Our easy to use setup, allows you to take advantage of this feature without any customization.



If Facility maps have been set up, they will appear in the Navigation Tree. As with layouts, facility maps are stored on particular servers. However, given the correct security access, you can view facility maps from any server. Facility maps can be layered for drill down purposes. You can set up a map for an entire town, then drill down to an individual campus, and then drill down to an individual floor. You can set up default facility maps for a server. For instance, the default facility map for the server is Lincoln.



By selecting the Lincoln Campus from the left navigation tree, the floor plan for Lincoln High School will appear. You can mouse over the camera and that camera's live image will appear in the pane to the right.

Objekty Facility Map - Lincoln Compos     Objekty Facility Map - Lincoln Compos     Objekty Facility Maps - Lincolny and - Lincolny Base - Decemposity Maps - De	
	- Grans-Honneber Caresa Honneber Caresa Honneber Caresa Honneber Caresa Honneber Caresa Honne Bootheres Assa Carese Caresa Honne Caresa Honneber Caresa Honneber Cares
5	

In the lower right hand corner is information on the camera, the Live Window option and the zoom in and out controls. By clicking on the 30 Seconds button, you can review the last 30 seconds of recording for that camera.

Camera Informat	on
Camera Number	822389 Live 30 Seconds
Camera Name	West Hall
Server Name	Southwest Area Campus
Z	

The left arrow moves the view to the next higher facility map if you have set up multi-level facility maps.



At the top of the facility map are options to show or

remove the cameras, camera names or camera ranges from the facility map.

	Opti	ons 👻	
		Change Font	
		Show Zoom Bar	

You can also change the font size on the camera names and remove the zoom bar from the camera view.

#### 2.3.4 Health Monitor

If there are Health Monitors set up and connected to this Monitor Station, then the red cross icon will appear. See the Setup and Configuration Guide for more information on Health Monitors.

#### 2.3.5 Action Items

Action items are essentially buttons that can be clicked to initiate certain actions. In this case, we have set up two buttons: Alert Campus Police and Alert Principal. When these actions are clicked, they automatically generate actions such as sounding an alarm or sending an email of a motion event. Action Items are setup using the Rules Manager. Please see the Setup and Configuration Guide for more information on Action Items and the Rules Manager.



#### 2.3.6 Facility Map View

When the Facility Map View is selected the tree structure changes from the Enterprise view (Server oriented) to a Map oriented tree



In this case we have set up three different maps: one for the South Campus, one for the Southwest Campus and one for the first floor. If you select one of the maps, then the list expands to show the cameras and the designated map appears.



You can then use the camera icons on the map to view the image from that camera.

#### 2.3.7 Layout View

When the Layout View is selected, the tree structure changes to a Layout oriented tree.



Select the layout from the tree structure and that layout will appear in the viewing pane.

#### 2.3.8 Right Click on Camera Name

When you right click on the camera, several options appear.



#### Live Window

When you select this option, a free floating live window for that camera pops up. You can move or enlarge this image by using your mouse.

## Send...

The Send function allows the user to send a copy of that live viewing pane to anyone that is logged in to another Monitor Station. When the option is selected the following screen appears:

Send to user	X		
Select the users you want to view this camera.			
All users			
Administrator			
pmilam			
N mflick			
📉 Mike			
🔲 james			
🔲 idoe			
Test User			
OK Cancel			

You can then select the users that you want to receive the live view of this camera. Please note that if the user does not have viewing rights to this camera, they will not receive the live view from the camera. In addition, only those users that are currently logged into the system will receive the live view from the camera.

#### View Camera

This option places this camera in the viewing pane.

#### Properties

By selecting this option, you will be taken to the corresponding camera setup screens. For more detail on camera setup, consult your Setup and Configuration Guide.

#### 2.4 PTZ and Audio Controls

At the bottom of the left navigation area are controls for PTZ cameras as well as Audio Controls. By clicking on the arrow, you collapse the controls so that they no longer appear in the left pavigation area

PTZ Controls		(*
$\square$	٦	
< 🔞	>	神神
⊾ 👳		
🔲 Use digita	IPTZ	
Audio Controls	\$	*
Delay Buffer	1 1	Balance: Volume:

#### 2.4.1 **PTZ Controls**

With the PTZ Controls, you can control the PTZ camera by clicking on the arrows to move the camera, clicking on the zoom in and zoom out buttons. When a PTZ camera is selected in the viewing panel, the PTZ controls affect the camera that is selected. Use Digital PTZ – When this is selected, there is no actual movement of the camera. You can also use the mouse scroll wheel to control zooming.

#### 2.4.2 **Audio Controls**

Balance - Balances sound between the left and right speakers. Delay Buffer - sets the size of the audio buffer. This can be adjusted when you have a slow network connection. Volume - sets the speaker volume.

# 2.5 Recorded Video

There are two ways of viewing recorded video: from the left navigation tree and from the Media Player. The Media Player provides the ability to view recordings by motion events and time lines and will be discussed in the next section.

#### 2.5.1 To View a Recorded File

Using the left navigation tree, click on a camera, date, and time.



Recorded files are organized into folders starting with Today. Click the folder to view the recorded files from today. The file names represent the time when the file was created. For example, 06h44m09s means 6:44:09AM. The system creates a new file whenever the file size has reached the specified size (default is 200mb). See the Setup and Configuration Guide for instructions on changing these settings. The file will play back in the viewer and you can use the navigation buttons to move through the file. The system stores its files in a standard AVI format with the camera name, date and time stored on the file. The file format is compatible with any Windows Media player and can be distributed without the requirement of a special viewer The system automatically creates a new file at midnight, regardless of size, to keep all files organized by date. Depending on the amount of activity and your settings, you might see as few as 1 file or as many as 20 files for a single day.

When you click on a recording, a playback screen will appear with the playback options shown below.



#### 2.5.2 Playback Buttons



#### 2.5.3 Saving a Clip

To save a clip, open the recorded file and press the Pause button to stop playback. Notice the "clip indicators" under the scroll bar. Drag the left indicator to the start of the clip and drag the right to the end of the clip. Once in position, click the diskette icon to bring up the clip menu. You can save the file to a folder or directly to a CD. If you save to a CD, the system will give you the option of include a Standalone Video Player with the clip.

💿 General Video	Clipper	×
This dialog will save	a portion of video. Select the file location, and press OK.	
Save to file		
<ul> <li>Save to file</li> </ul>		
File name	C:\Documents and Settings\lrichardson\My Document	
🔿 Save to CD		
File Name	TEMP_CLIP.AVI	
	Burn the CD when complete	
		5
l		
	OK Cancel	

The system stores its files in a standard AVI format with the camera name, date and time stored in the path and file name. on the file. The file format is compatible with any Windows Media player. Recorded files can be distributed without the requirement of a special viewer or any conversion.

#### 2.5.4 Save a Clip on CD

After a clip has been created or a file has been saved to the CD, an information box will display on the bottom toolbar with the message "You have files waiting to be written to the CD". Click on this message to start the process of saving a clip to the CD.

- 1. Click "Next" on the CD Writing Wizard.
- 2. Put a blank CD in the drive.
- 3. Click on the "Write these files to a CD"
- 4. The process will automatically complete. Remove the CD from the drive when the process says it is complete.



#### 2.5.5 Downloading the entire file

If you need to save the entire file to a CD or other Windows media mouse click on the



This action opens a Browse dialog box that you can use to save the file to a local computer or other media.

#### 2.5.6 Object Search

The software includes many tools to help review recorded video. One of these tools is the smart, or object search tool.

# When the Object button is selected, the following additional buttons appear.

Begin Object Search



And Object Search Options

From the left navigation tree, select the camera and the day you wish to search First select the recorded file from the drop down box that you wish to search. The first image of the file will be displayed. Using the mouse, hold the left button down and draw a box on the screen where you want to search. Click the "Next" button. The file will automatically advance to the next frame that has movement inside the box. Clicking "Next" again, advances the file to the next instance. Clicking the "Play" button will play the video from that point forward. The system will search from one file to

another until it finds movement inside the box. You can adjust the sensitivity from the drop down menu if it's finding too much or too little. If you need to abort the search, click "Cancel."



the recorded video

Using Object Search, draw box around briefcase

Object Search forwards the file to the proper location

#### Zoom On Playback 2.5.7

The software provides the ability to zoom on playback as well as live view. To zoom in on a picture, position the mouse on the upper left hand corner of the area that you want to zoom in on, then press the left mouse button and drag the mouse over the area to be zoomed. The system will then zoom in on the area. To zoom out, position the mouse in the lower right hand corner, then press the left mouse button and drag the mouse back over the area. The system will then zoom out to the original view. You can then use the PTZ controls in the left pane to control the zoom function as a digital PTZ. You can click on the middle of the camera image to return to the normal view.

#### 2.5.8 **Object Zoom and Print**



When you click on the Object Zoom the playback pauses and a new window appears.



Using the Object Zoom, you can save the current image.

Increase or decrease the size of the Window



Or Print the current image in the window.



You can also use the zoom function described above, i.e. left click on the area to be zoomed.

## 2.6 Media Player

You may also use the Media Player to view recorded video. The Media Player provides the ability to view recordings by motion events and time lines. To access the Media Player, Select Tools from the top tool bar and then select Media Player



Recorded files are organized into folders starting with Today. Click the folder to view the recorded files from today. The file names represent the time when the file was created. For example, 06h44m09s means 6:44:09AM. The system creates a new file whenever the file size has reached the specified size (default is 200mb). See the Setup and Configuration Guide for instructions on changing these settings. The file will play back in the viewer and you can use the navigation buttons to move through the file. The system stores its files in a standard AVI format with the camera name, date and time stored on the file. The file format is compatible with any Windows Media player and can be distributed without the requirement of a special viewer The system automatically creates a new file at midnight, regardless of size, to keep all files organized by date. Depending on the amount of activity and your settings, you might see as few as 1 file or as many as 20 files for a single day.

#### The Media Player's screen layout has the following sections:

- Selection panel which determines what recording is played
- Viewing panel (Playback panel)



#### 2.6.1 Selection Panel

There are four ways to select video recording to be played

- Browse Video Servers
- Browse Folders for Video
- Quick Select
- Motion Events
- Player Controls

Use the down and up arrows to select the option.

Browse Video Servers The Browse Video Server option uses a tree structure consisting of servers, cameras, and dates.

rowse Video Servers	~
a  Main Campus a-aa East Hallway a-aa Yesterday ioo 14h20m17s aa Cafeteria	
Careteria     Careteria     West Hallway     Yesterday     Yesterday     Government     Main Entrance     Today     Yesterday     Yesterday     Yesterday     Z3h00m53s     Z3h04m46s	
00 23h55m30s 00 23h59m23s	
rowse Folders for Video	*
	~
otion Events	~

igate to the desired server, camera, date, and time to select the recorded video to be played.

When you click on a recording, a playback screen will appear with the playback options shown below.



#### 2.6.2 Playback Buttons



#### 2.6.3 Saving a Clip

To save a clip, open the recorded file and press the Pause button to stop playback. Notice the "clip indicators" under the scroll bar. Drag the left indicator to the start of the clip and drag the right to the end of the clip. Once in position, click the diskette icon to bring up the clip menu. You can save the file to a folder or directly to a CD. If you save to a CD, the system will give you the option of include a Standalone Video Player with the clip.

🙆 General Video	Clipper	×
dialog. Select the file	a portion of video based off of the settings from the pre a location, and press OK.	vious
Save to file	Force to Motion JPEG	
File name	C:\Documents and Settings\Irichardson\My Document	
Save to CD		
File Name	TEMP_CLIP_ 0.avi	

The system stores its files in a standard AVI format with the camera name, date and time stored in the path and file name. on the file. The file format is compatible with any Windows Media player. Recorded files can be distributed without the requirement of a special viewer or any conversion.

#### 2.6.4 Save a Clip on CD

After a clip has been created or a file has been saved to the CD, an information box will display on the bottom toolbar with the message "You have files waiting to be written to the CD". Click on this message to start the process of saving a clip to the CD.

- 5. Click "Next" on the CD Writing Wizard.
- 6. Put a blank CD in the drive.
- 7. Click on the "Write these files to a CD"
- 8. The process will automatically complete. Remove the CD from the drive when the process says it is complete.



#### 2.6.5 Downloading the entire file

If you need to save the entire file to a CD or other Windows media mouse click on the

Y
---

This action opens a Browse dialog box that you can use to save the file to a local computer or other media.

#### 2.6.6 Zoom On Playback

The software provides the ability to zoom on playback as well as live view. To zoom in on a picture, position the mouse on the upper left hand corner of the area that you want to zoom in on, then press the left mouse button and drag the mouse over the area to be zoomed. The system will then zoom in on the area. To zoom out, position the mouse in the lower right hand corner, then press the left mouse button and drag the mouse back over the area. The system will then zoom out to the original view. You can then use the PTZ controls in the left pane to control the zoom function as a digital PTZ. You can click on the middle of the camera image to return to the normal view.

#### **Browse Folders for Video**



Using this option, you can browse folders directly on the server or other servers attached to the network. This option does not use the streaming to the Monitor Station to play recorded video. Note that in order to play video through this option, you must have the correct CODEC installed on your computer.

#### **Quick Select**

Using this option you can select recordings based on a calendar and timeline.



When a day is selected from the calendar, the timeline view will appear at the top of the viewing panel.



The Timeline chart is a graphical representation of where motion occurred throughout the day.

	$\sum_{\square}$	2		Э		Ĥ	ę	26	7	2																
ĺ	₽01  }	02 	03	04 	05 	06 	07 	08 	09 	10 	11 	12 	13 	14 	15 	16 	17 	18 	19 	20 	21	22 	23 			+
																								_	Ī	-

By clicking on the blue lines, the system will play that piece

of video. It's a great tool for quickly reviewing the previous day's video. You can also zoom in on the timeline chart by selecting the "+" button on the right.

#### **Motion Events**

1	Notion Eve	ents						~				
	Server Main Campus   Reload											
ſ	Cameras East Hallway (10.10.1.158) Basic Basic Mest Hallway (10.10.1.230) Main Entrance (10.10.1.221) Minimum Motion 5 3 %											
	Not B	efor}	re: 2/18/2	800	12:49	8:19	9 PM 🔤 🤤					
	📃 Not A	After:	2/18/2	800	12:49	9:19	B PM 🔒 🗘					
[	Day		Time	%	File		amera	~				
	02.18.08		10:15 AM	64	10h15m21s		afieteria	H				
	02.18.08			17	10h15m21s		afeteria					
			10:33 AM			-						
	02.18.08		10:52 AM	12	10h15m21s	C	Cafeteria					
	02.18.08		10:59 AM	54	10h15m21s		Cafeteria					
	02.18.08		11:15 AM	12	10h15m21s	С	afeteria					
	02.18.08		11:15 AM	31	10h15m21s	C	afeteria					
	02.18.08		11:16 AM	6	10h15m21s	С	afeteria					
	02.18.08		11:17 AM	8	10h15m21s	С	afeteria					
	02.18.08		11:18 AM	7	10h15m21s	С	afeteria					
	02.18.08		11:18 AM	5	10h15m21s	С	afeteria					
	02.18.08		11:18 AM	6	10h15m21s	С	afeteria					
- 1						-						

The Motion Event Log is a very powerful tool that allows you to rapidly review recorded events. The system creates an entry that includes the camera name, time and duration each time a camera detects motion. For example, if you review the video in the morning from the previous night, you can start by looking at the Motion Event Log. Select the camera and the date desired. Clicking on an entry plays just that piece of the video and gives you a quick snapshot of the night's events. The Motion Event Log can keep as many days of history as you feel is necessary and all entries are stored in the Microsoft SQL database. You can enable the Motion Event Log by accessing the Server and selecting the Setup/Server Configuration/Advanced Tab. The system also gives you the capability to label events (event tags). You can set up a specific event such as Door Open that reflects a specific motion event rather than just motion on a camera. For instance, you can set up an event label called Door Open. When that event occurs, an entry in the event log shows that label. Event labels are set up under Setup and Configuration/ Camera Configuration, Motion Settings.

#### 2.6.7 Media Player Tool Bar



The tool bar on the Media Player presents icons for the easy navigation between various ways of selecting recordings to be viewed as well as zoom in and out functionality.

#### 2.6.8 Single Player

When the Single Player icon is selected, the Browse Folders for Video selection option appears in the selection panel to the left. Click on the file to be played.

#### 2.6.9 Timeline View

When the Timeline View icon is selected, the Quick Select option appears in the selection panel on the left. Click on the day and then select the time from the timeline chart.

#### 2.6.10 Motion Events

When the Motion Events icon is selected the Motion Event option appears in the selection on the left. Select the Motion event that you want to view.

#### 2.6.11 Open File

#### 2.6.12 Increase/Decrease Playback size

This option increases or decreases the size of the viewing panel for playback

#### 2.6.13 Magnify Current Image and Print

When you click on the Magnify Current Image a new window appears.



Using the Object Zoom, you can save the current image.



Increase or decrease the size of the Window





You can also use the zoom function described above, i.e. left click on the area to be zoomed.

# 3 Pull Down Menus

File	e View	Tools	Administration	Help
3.1	File			
	Media Fi>	œr		
43	Exit			

#### 3.1.1 Media Fixer

If the server is shut down unexpectedly due to a power outage or other situations that correct a video file, you can repair the damage with the Video Fixer. This utility examines the file and deletes any corrupted portions that prevent the file from playing. To fix a file:

- 1. Click the "Open File" button to select the file to be repaired.
- 2. You can use the Remove file or Remove all files button.

3. Once the file has been specified, click the Fix button to start the process. This function is for fixing a file on the local system. If you want to fix the file on the server, you should right click on that file, and the video server will perform the media fixing.





3.1.2 Exit

Exits the application

#### 3.2 View

K	Left Panel		
-	Full Screen	F11	
	Layout		•
	Layout Order		
	Mini Toolbars	•	
	Status		•
	Toolbars		•

The View Pull Down menu presents an easy to use means for choosing to display or not display various sections of the screen.

#### 3.2.1 Left Panel

To remove the left panel from the display, uncheck the Left Panel option. After this has been unchecked, only the camera views will display.

#### 3.2.2 Full Screen

You can maximize the viewing area by clicking on "Full Screen" or hitting the F11 key (exit full screen with F11). This mode will expand the images to full screen, hide the left navigation tree and hide the tool bars. Once in this mode, you can navigate between the layouts by using the F1-F10 keys. By enabling security you can prevent users from exiting the full screen mode.

#### 3.2.3 Layout

Using the Layout option under View is another way of selecting the layout of the cameras on the viewing screen. This option also shows the function keys that can be used to toggle between layouts.

<b>~</b>	Left Panel		
	Full Screen F11		
	Layout 🔶 🕨	1 Camera Layout	F1
	Layout Order 🤟	4 Camera Layout	F2
	Mini Toolbars 🔹 🕨	8 Camera Layout	F3
	Status 🕨	9 Camera Layout	F4
	Toolbars 🕨 🕨	10 Camera Layout	F5
		13 Camera Layout	F6
		13 Camera Layout - 2	F7
		16 Camera Layout	F8
		25 Camera Layout	F9
		32 Camera Layout	F10

#### 3.2.4 Layout Order

This option displays the order of the cameras in the various 1, 4, 16, and 32 camera layouts.



#### 3.2.5 MiniToolbars



This feature turns on the automatic cycling. When this is activated the server will cycle between all 32 cameras via 1, 4, or 9 camera layout. You can also create your own customized layouts for cycling by selecting the button on the right circled in red. Clicking on the arrow will begin the cycling. You can turn off the cycling by clicking on the box.



#### PTZ Control





Cycle through all PTZ cameras

Cycles through the presets on that camera



Stops movement

The options shown on the PTZ controls depend on the specific camera. For example, if the camera does not support focusing, those buttons will be hidden.



When Server Status in turned on, then the status of all servers appears at the bottom of the viewing pane.

#### 3.2.7 Toolbars ~ Left Panel Full Screen F11 Layout ۲ Layout Order Mini Toolbars ۲ Status ۲ Toolbars ۲ ~ Layouts μŝ ~ Login ~ Widescreen Layouts

Use these options to remove layout buttons from the screen. If you do not wish to show the login id of the current user at the upper left hand corner of the left panel, turn the login option off.

## 3.3 Tools

5r	System Log						
	Axis Joystick Control						
	Facility Map Selector						
	Live Window						
	Media Player						
	PTZ Operations						
	Synchronized Player						
	Options						

## 3.3.1 System Log

The System Log allows you to view all system events that have occurred. The Date and Time of the action as well as the Message is shown. System events include logs of the details of what changed on cameras and servers as well as server shutdown.

Log Téle	Veronge -	~
400 21719 M	administration has longed in al 21 x 1 x < 2002	-
400 TH 16 M	he meal of her liver out	
400 F 00 M	the prevalent back were out	
(10) 125 (0.34)	he meal of her liver out	
400 - 12 7 St M	he creater had been out	
400 T19977AH	he meal of her liver out	
408 - 115771 AH	he creater had been out	
400 005-200 AH	he meal of her liver out	
400 - 10H STAH	administration has longed in all TEM ( Av. ). All 2	
400 - 10 - 30AH	administration has longed and TH = Av < 700	
400 - 105 / 26AH	he creater had been out	
700 957 17 AH	he meal of her liver out	
400 955 BLAH	he mercian back end of	
700 955 005H	he mediation for liver and	
400 9 / 10.5H	he consider had been out	
406 9 4 STAR	he stepling had been out	
708 9 4 STAR	he mercian had investigat	
708 05-207-5H	he stepling had been ad	
408 0E4078B	he creater had been out	
AND REPORT	he ment of her liver out	

## 3.3.2 Axis Joystick Control

This option links to the standalone executable for the Axis Joystick. You can then use the joystick to move the PTZ.

Axis Joystick Support				
Axis Joystick support				
	Username root			
	Password	***		
Current Camera URL				
http://10.10.1.201/user/cgi-bin/view_S_t_uF.thtml				
Button Controls				
Press button to select an IP camera				
Preset 1	1	2	Preset 2	
Preset 3	3	4	Preset 4	
	5	6		
	7	8		
	9	10		
Config Settings Save Exit				
### 3.3.3 Live Window

When Live Window is selected, a new window will be opened. You can select the camera to be viewed and move the window around the screen or across multiple monitors.

### 3.3.4 PTZ Operations

You can control Pan-Tilt-Zoom cameras from the Monitor Station or Web Client These controls allow you to move the camera in all directions and save preset locations for quick access. In addition, you can cycle through presets in a specified interval. This cycling can be started and stopped from the Monitor Station and the Web Client. You can setup up to 16 PTZ cameras per server under the Setup/Cameras/PTZ setup screen and all 16 cameras can be cycled. If you manually move a cycling camera, the cycling will pause for 30 seconds then resume the preset cycle.



### 3.3.5 Synchronized Playback

With the Synchronized Playback function you can achieve perfect playback of recorded files between 1 and 16 cameras. When Synchronized Playback is selected, point the system to the correct folder with the video from the cameras to be displayed. Once the folder is selected, the following screen appears:



Select the desired folder of video recordings, then select the cameras to be viewed.

Select the date of the recordings. Once the date has been selected, a time line appears with an indication of times of motion for each camera. To select a time frame to view, move your cursor along the time line, and then left click and drag the cursor to highlight the time frame. In the example below, the time between 12 noon and 2 PM will be viewed.



One the time frame has been selected, select the play button at the bottom of the screen. The system will begin the synchronous display of the selected cameras. Note also that at the bottom of the picture, there is a time line as well, This is a detailed time line of the period selected from the Time frame on the left. Note also that you can drag the pointer to anywhere along the time line.



### 3.3.6 Media Player

See description of Media Player above.

### 3.3.7 Options

See the description of the Monitor Options in the Setup and Configuration Guide.

### 3.4 Administration

The Administration tab is discussed in the Setup and Configuration User Guide.

### 3.5 Help

45	License Agreement
	Online IP Address
	Online Support
	Remote Support
	About Video Insight

### 3.5.1 License Agreement

This option links to the License Agreement. When software is first installed, the terms of the agreement must be accepted.

### 3.5.2 Online IP address

Looks up your current external IP address.

### 3.5.3 Online Support

Brings up a pdf of the documentation

### 3.5.4 Remote Support

The Remote Support option sets up a connection so that Technical support can make a VNC connection into your server. Before making a connection, please call Technical Support at 713 621 9779. They will indicate which support line to use.

Support 1 Support 2 Support 3 Support 4 Support 5 Support 6 Support 7	VIDEOINS Tech Suppo	
Double Click to make a connection	Video Insight DVR Suppor	t
Before making a connection Please Call 800.513.5417 opt.2 for Support	More Info	CLOSE

### 3.5.5 About Video Insight

The Video Insight About shows the version, model number,. In addition it shows the Name and Company that are licensed to use this product and the authorized phone number. This phone number must be referenced when calling for technical support.

About Video Insight 🛛 🛛 🔀				
	Monitor Station			
	Video Insight			
	All rights reserved.			
	Version:4.0.0.0			
	Language: English (United States)			
Executed from:				
C:\Program Files\Video Insight\Video Insight Monitor Station\Mo				
Warning: This computer program is protected by copyright law and internationional treaties.				
This product is licensed. Unauthorized reproduction or distribution of this program, or any portion of it, may result in severe civil and criminal penalties, and will be prosecuted to the maximum extent possible under the law.				
Technical Support Information OK				

# 4 Web Client

For even greater access, the IP Server automatically creates a website that can be viewed from any web browser like Microsoft Internet Explorer or Netscape. You can view cameras from multiple servers at the same time and view recorded video from any of the cameras. The Web Client has all the basic functionality of the Network Client without having to load any software on the remote PC. This is very useful if your organization has restrictions about loading applications or is using other browsers. The system is compatible with all browsers including Apple Macintosh. You can control PTZ cameras online. The system supports multiple users and is tightly integrated into the Windows operating system for complete security. Our Web Client is with Microsoft's Internet Information Servers (IIS). This allows us to take advantage of IIS' scalability and flexibility. You can change the port or take advantage of Dynamic or Static IP addresses. By utilizing security, you can restrict users from viewing specific cameras and their ability to play recorded files.

## 4.1 Support for Mobile Devices

The software currently supports IE Mobile and Opera Mobile Support for IE Mobile. When you log into the web client the system detects the use of IE mobile and changes the format so that it properly displays on a smaller screen size.

The video will now smoothly display giving you the ability to select different cameras, and perform PTZ commands from your mobile device.

## 4.2 Screen Layout

To access the web client use <u>http://<yourip>/videoinsight4</u> in the address line of your browser. If security has been enabled, a user id and password will be required.

After you login, the following screen appears:



There are two main sections of the screen:

- Left Navigation tree structure (outlined in blue) which can be used to navigate from camera to camera and to view recorded files.
- Viewing Panel (outlined in red)

### 4.3 Left Navigation Tree Structure

The Left Navigation Tree Structure on the Web Client functions in a manner very similar to the Monitor Station. You have the options of the Enterprise View which shows all of the servers, facility maps and layouts in sequence, or the Facility Map view or the Layout View.

### 4.3.1 Enterprise View



Under this view, a listing of all servers, cameras, layouts and facility maps is shown. From the list of the cameras, maps or layouts, you select the cameras that you wish to appear in the Viewing Pane. You may also select a layout or a facility map.

### 4.3.2 Facility Map View

As with the Monitor Station, you can also select the Facility Map view. Once you select a facility map, the map appears in the viewing pane. You can click on the camera icons on the maps to view images from that camera.



### 4.3.3 Layout View

The Layout View brings up the list of predefined layouts. Select the layout and the images from that layout appear.



### 4.3.4 PTZ Control

You can control a PTZ camera by expanding the Pan Tilt Zoom Option at the bottom of the left navigation tree.

Pan Tilt Zoom		÷
<b>.</b>	Zoom	+
	Focus	+
	Shutter	+
Presets	Cycle	
	V Off	~

**4.4** Viewing Panel Once you have selected the cameras or layouts from the left navigation tree, the images from those cameras will appear in the Viewing Pane



### 4.4.1 Layout Option

Select the type of layout to be used in viewing the camera images. Best fit – takes the number of cameras to be viewed and determines which layout is the best fit for the number of cameras. Or you have the option of selecting one of the predefined layouts.

Best Fit	▼
Best Fit	v.
1 x 1	4
2 x 2	1 1 1
1 x 7	
1 x 12	61.03
4 x 4	a
5 x 5	9
3 x 3	5
2 x 8	
6 x 5	

## 4.4.2 High Speed Mode

By checking this option, you will enable Video Streaming.

## 4.5 Web Client Tool Bar

WEB CLIENT Maps   ► Live   Events   H
---------------------------------------

### 4.5.1 Live View

When the web client is first opened, this Tool Bar will be set to Live. When Live is selected, the camera images in the Viewing Pane are live images.

### 4.5.2 Maps

When the Maps Option is selected, only the Facility maps will appear on the web client. The left navigation bar will disappear.



### 4.5.3 Events

To view recorded images, select the Events Option.

When the Media Option is selected, the system brings up the Media Player.

As with the "Live view", the system gives you the option to view and select the camera recordings via the Enterprise, Facility Map, or Layout view. There are two sections of the

### 4.5.4 Camera Selector

Left pane in the Media Player: the navigation tree (Enterprise, Facility Map, or Layout Views) used to select cameras and recordings; and the Events Pane used to view recordings based on motion events.

	interprise Di	irectory 🔻 🌐 👬 📕		
- OII All Servers				
🖃 🐖 Southeast Campus				
	🛨 💼 East Stairwell			
	Elementary School Wing Entra			
		West Entrance		
		Main Entrance		
		Pick Up area		
		Front Circle Drive		
		School Bus Ston		
<	It is a			
	anta (la mant	202000		
	ents (lement	ary S) 3/9/2009 🛄 :		
÷	12 am	97 events		
+ +	12 am 1 am	97 events 95 events		
+ + +	12 am 1 am 2 am	97 events 95 events 96 events		
+ + + +	12 am 1 am 2 am 3 am	97 events 95 events 96 events 99 events		
+ + + +	12 am 1 am 2 am 3 am 4 am	97 events 95 events 96 events 99 events 96 events		
+ + + + +	12 am 1 am 2 am 3 am 4 am 5 am	97 events 95 events 96 events 99 events 96 events 100 events		
+ + + + + +	12 am 1 am 2 am 3 am 4 am 5 am 6 am	97 events 95 events 96 events 99 events 96 events 100 events 96 events		
+ + + + + + +	12 am 1 am 2 am 3 am 4 am 5 am 6 am 7 am	97 events 95 events 96 events 99 events 96 events 100 events 96 events 91 events		
+ + + + + + + + + +	12 am 1 am 2 am 3 am 4 am 5 am 6 am 7 am 8 am	97 events 95 events 96 events 99 events 96 events 100 events 96 events 91 events 95 events		
+ + + + + + + + + + + +	12 am 1 am 2 am 3 am 4 am 5 am 6 am 7 am 8 am 9 am	97 events 95 events 96 events 99 events 96 events 100 events 96 events 91 events 95 events 95 events 96 events		
+ + + + + + + + + + + +	12 am 1 am 2 am 3 am 4 am 5 am 6 am 7 am 8 am 9 am 10 am	97 events 95 events 96 events 99 events 96 events 100 events 96 events 95 events 96 events 96 events 96 events 96 events 96 events		
+ + + + + + + + + + + + + + +	12 am 1 am 2 am 3 am 4 am 5 am 6 am 7 am 8 am 9 am 10 am 11 am	97 events 95 events 96 events 99 events 96 events 100 events 96 events 91 events 95 events 95 events 95 events 97 events		
+ + + + + + + + + + + +	12 am 1 am 2 am 3 am 4 am 5 am 6 am 7 am 8 am 9 am 10 am	97 events 95 events 96 events 99 events 96 events 100 events 96 events 95 events 96 events 96 events 96 events 96 events 96 events		

To view recorded video, select the camera and then expand to select the date and individual recordings.



The selected recording video will appear in the Viewing Pane. The playback controls will depend on whether Streaming is enabled. If streaming is not enabled, then a simplified playback control appears.



Use the Slider bar to navigate through the recording. To create a clip, click on the Clip icon and set the clip indicators to the portion of the recording that you want to save. Then click on the Download Clip Icon.





Save the clip to the desired media or directory.

If Streaming is Enabled, then the more robust playback controls appear. 03/05/2009 08:02:16:546

These controls function in exactly the same manner as the Playback controls in the Monitor Station client.

### 4.5.5 Event Log

When a particular camera is selected in the navigation tree, the corresponding motion events for that camera for the current date appear in the pane below:

Eve	ents (lementa	ary S) 3/9/200	9
+	12 am	97 events	
+	1 am	95 events	
+	2 am	96 events	
+	3 am	99 events	
+	4 am	96 events	
+	5 am	100 events	
+	6 am	96 events	
+	7 am	91 events	
+	8 am	95 events	
+	9 am	96 events	
+	10 am	95 events	
+	11 am	97 events	
+	12 pm	97 events	
Ē	1.000	05 overte	

Select the desired time and the view expands to show all of the motion recordings for that time.

-	1 am	95 events
	01:00:06 AM	8 sec
	01:00:20 AM	23 sec
	01:00:51 AM	5 60 sec
	01:01:51 AM	9 sec
	01:02:06 AM	22 sec
	01:02:37 AM	60 sec
	01:03:37 AM	8 sec
	01:03:51 AM	23 sec
	01:04:22 AM	60 sec
	01:05:22 AM	9 sec

Select the desired motion event and the recording appears in the viewing pane.

You can use the calendar selector to change the date from the current date to a previous date.

Events (lementary S...) 3/9/2009

### 4.6 Help

In the upper right hand corner of the web client view is the Help option.



### 4.6.1 Location Setup

### 4.6.2 License Agreement

This option links to the Video Insight License Agreement. When Video Insight is first installed, the terms of the agreement must be accepted.

### 4.6.3 Help on the web

This option links to the Video Insight Support pages. These pages offer helpful tips and answers to frequently asked questions.

### 4.6.4 User Manual

This option links to the User Manual in PDF format. The manual can be viewed online or printed for later reference.

### 4.6.5 About Video Insight

The Video Insight About shows the version, model number, and serial number for the product. It also shows the dates that technical support will no longer be available as well as the dates after which no product upgrades will be available. In addition it shows the Name and Company that are licensed to use this product and the authorized phone number. This phone number must be referenced when calling for technical support

5 <u>Technical Support Options</u> Your registered Video Insight product includes a one year software maintenance and technical support plan that begins on your purchase date. You can contact Video Insight's technical support staff by phone or by e-mail to receive one-on-one support when you are experiencing issues or have questions.

Online: <u>www.video-insight.com/support</u> Email: support@video-insight.com Call: 800-513-5417